

3rd Party Approved products for use with Rapid Response[®] boards

Mapei Products: Ultrabond Eco 380

Use: As an alternative to WundaSpray adhesive to bond boards to subfloor

Consumption/Notes: 2mm bed, 15Kg covers 35m² using an A2 trowel

Manufacturers Link: Ultrabond Eco 380, Solvent-Free Vinyl/PVC Adhesive | Mapei UK | Mapei UK

Ultrabond Eco S955 1K

Use: To bond ply or wood directly to the rapid response boards

Consumption/Notes: 15Kg covers 13m². Applied with a V or square notched trowel with 10mm ridges

Manufacturers Link: Ultrabond Eco S955 1K, Polymer-Based Adhesive | Mapei UK | Mapei UK

Eco Prim Grip

Use: To prime the surface of the boards, pipework & empty pipe channels before application of Ultraplan renovation screed

Consumption/Notes: Use neat, 5Kg tub covers 16m²

Manufacturers Link: ECO PRIM GRIP PLUS, technical sheet | Mapei UK

Ultraplan Renovation Screed

Use: A self-levelling compound for boards primed with Eco Prim Grip, to provide a smooth surface for certain floor finishes

Consumption/Notes: 1.8m² per 25Kg bag @ 10mm depth. (recommended to infill empty pipe channels first)

Manufacturers Link: ULTRAPLAN RENOVATION SCREED 3240, technical sheet | Mapei UK

Kerabond T White/Grey

Use: Slow setting, highly deformable, cementitious tile adhesive. Mixed with Isolastic (100:33)

Consumption/Notes: At a 6mm bed 20Kg covers 4m². *Bed thickness depends on tile thickness

Manufacturers Link: KERABOND T, technical sheet | Mapei

3rd Party Approved products for use with Rapid Response[®] boards

Isolastic

Use: To be mixed with Kerabond T

Consumption/Notes: 100:33 Kerabond T : Isolastic 3.3 litres for every 10Kg, or 6.6 litres for every 20Kg of Kerabond T

Manufacturers Link: ISOLASTIC, technical sheet | Mapei

Ultra Products:

Prime IT MSP

Use: To prime the surface of the boards, pipework & empty pipe channels prior to the application of Proflex S2, or Ultra levelling compound

Consumption/Notes: Apply neat, 50m² per 5L tub

Manufacturers Link: Prime IT Multi-surface Primer – Instarmac

Proflex S2. White/ Grey

Use: Fast setting, highly deformable cementitious tile adhesive. Boards must be primed before use. Infill any empty channels before tiling over

Consumption/Notes: At a 3mm bed 20Kg covers 4m². *Bed thickness depends on tile thickness

Manufacturers Link: ProFlex S2: Fibre Reinforced Flexible Tile Adhesive – Instarmac

ProLevel Ultimate

Use: Replacing Level IT Two. A self-levelling compound for boards primed with Prime IT, to provide a smooth surface for certain floor finishes

Consumption/Notes: 1.2m² @ 10mm depth per 20Kg (recommended to infill empty pipe channels first)

Manufacturers Link: ProLevel Ultimate – Instarmac

Level IT Two (Legacy recommendation)

Use: As a self-levelling compound for boards primed with Prime IT, to provide a smooth surface for certain floor finishes. Comes with bottle of liquid to mix

Consumption/Notes: 1.2m² @ 10mm depth per 20Kg (recommended to infill empty pipe channels first)

Manufacturers Link: <https://www.instarmac.co.uk/products/ultrafloor/smoothing-underlayments/level-it-two-high-flow-two-component-smoothing-underlayment/>